


FESTO

FluidLab® PA
closed-loop

Manual

V 4.0



Intended use

This software has been developed and produced solely for vocational and further training purposes in the field of automation and communication. The company undertaking the training and / or the instructors is / are to ensure that trainees observe the safety precautions described in the manuals provided.

Festo Didactic herewith excludes any liability for damage or injury caused to trainees, the training company and / or any third party, which may occur if the system is in use for purposes other than purely for training, unless the said damage / injury has been caused by Festo Didactic deliberately or through gross negligence.

Order No.:

Description: Manual

Designation: Fluid Lab®-PA closed-loop Software

Status: 09/2014

Authors: Jürgen Helmich, Adiro Automatisierungstechnik GmbH

Graphics: Thomas Schwab, Adiro Automatisierungstechnik GmbH

Layout: Jürgen Helmich, Adiro Automatisierungstechnik GmbH

© Festo Didactic GmbH & Co., D-73770 Denkendorf, 2014

Internet: www.festo.com/didactic <http://www.festo.com/didactic/de/ProcessAutomation>


e-mail: did@festo.com

The copying, distribution and utilisation of this document as well as the communication of its contents to others without express authorisation of is prohibited. Offenders will be held liable for the payment of damages. All rights reserved, in particular the right to carry out patent, utility model or ornamental design registration.

Contents

| | | |
|----------|---|-----------|
| 1 | Introduction | 4 |
| 1.1 | Training contents | 6 |
| 1.2 | Important notes | 6 |
| 1.3 | Duty of the operating authority | 6 |
| 1.4 | Duty of trainees | 7 |
| 1.5 | Risks involved in dealing with FluidLab® PA closed-loop | 7 |
| 1.6 | Warranty and liability | 7 |
| 1.7 | Use for intended purpose | 8 |
| 2 | Installation | 9 |
| 2.1 | Design | 9 |
| 2.2 | FluidLab® PA closed-loop program files | 9 |
| 2.3 | EasyPort USB driver | 9 |
| 2.4 | LabVIEW® runtime engine | 9 |
| 2.5 | Requirements for usage | 9 |
| 2.6 | Starting installation | 11 |
| 2.7 | Selecting the set-up language | 11 |
| 2.8 | Welcome window | 12 |
| 2.9 | Uninstall the FluidLab® PA closed-loop | 13 |
| 3 | Design and function | 14 |
| 3.1 | Programm administration | 14 |
| 3.2 | Main menu | 15 |
| 3.3 | Licence input | 16 |
| 3.4 | Information | 17 |
| 3.5 | Setup | 18 |
| 3.6 | Changing texts | 23 |
| 3.7 | Graph adjustment | 26 |
| 3.8 | Measuring and Control | 27 |
| 3.9 | Characteristics | 30 |
| 3.10 | Closed loop – 2 point | 32 |
| 3.11 | Continuous loop control | 34 |
| 3.12 | Saving results as ASCII files | 36 |
| 4 | Trouble shooting | 39 |
| 4.1 | Easyport | 39 |
| 4.2 | User interface | 39 |
| 5 | Appendix | 40 |
| 5.1 | Examples for system responses | 40 |
| 5.2 | Examples for closed loop controls | 45 |
| 5.3 | Controller parameters | 49 |
| 5.4 | I/O assignment list | 50 |

1 Introduction



FluidLab®-PA closed-loop start up window

The FluidLab® PA closed-loop software in combination with the EasyPort USB offers you the possibility to measure and analyze the signals of 8 digital/4 analog inputs.

The electrical control interface (E/A Syslink and analog terminal) is the same like MPS.

Three main functions are integrated in FluidLab® PA closed-loop:

- M as in **m**easurement, for signal detection and analysis of 8 digital/4 analog input signals
- C as in **c**ontrol, for binary or continuous control of 8 digital/2 analog outputs
- R as in **r**egulate a closed-loop system, free selectable closed-loop control elements for 2-point, P, I, PI and PID

With the Compact Workstation of the learning system for process automation you have the possibility to work with the following systems:

- level controlled system
- flow rate controlled system
- pressure controlled system
- temperature controlled system

It is possible to work with the following functions by using the 4 closed-loop systems:

- two point control of a level control system with a analog standard signal
- continuous control of a level control system with a analog standard signal
- continuous control of a flow rate control system with a pump as controlled system and with a analog standard signal
- continuous control of a flow rate control system with a proportional valve as controlled system and with a analog standard signal
- continuous control of a pressure control system with a pump as controlled system and with a analog standard signal
- continuous control of a pressure control system with a proportional valve as controlled system and with a analog standard signal
- two point control of a temperature control system with a analog standard signal

Alternatively you are able to work with a simulation environment, with which you can simulate the systems of a Compact Workstation.

By using the simulation environment with the continuous loop control you can simulate the following functions:

- level controlled system
- flow rate controlled system
- temperature controlled system

By using the simulation environment with the continuous loop control you can simulate the following functions:

- level controlled system
- flow rate controlled system
- temperature controlled system

1.1

Training contents

Training contents covering the following subjects can be taught:

- Sensors
 - Correct use of sensors
 - Measuring of non-electrical, process and control variables
- Closed-loop control technology
 - basics of closed-loop control technology
 - Extension of measuring chains into closed control loops
 - Analyze a closed-loop system
 - P, I, D-control
 - Optimize a closed-loop system
- Closed-loop controller
 - Configuration, assigning operation parameters and optimization of a closed-loop controller
- Commissioning
 - Commissioning of a closed-loop system
 - Commissioning of a process engineering system
- Fault finding
 - Systematic fault finding on a process engineering system
 - Examination and maintenance of a process engineering system
 - Operation and observation of a process

1.2

Important notes

The basic requirement for safe use and trouble-free operation of FluidLab® PA closed-loop is to observe the fundamental safety recommendations and regulations.

These operating instructions contain important notes concerning the safe operation of FluidLab® PA closed-loop.

The safety recommendations in particular must be observed by anyone working on FluidLab® PA closed-loop as well as for the used hardware.

Furthermore, the rules and regulations for the prevention of accidents applicable to the place of use must be observed.

1.3

Duty of the operating authority

The operating authority undertakes to ensure that FluidLab® PA closed-loop is used only by persons who:

- are familiar with the basic regulations regarding operational safety and accident prevention and who have received instructions in the handling of FluidLab® PA closed-loop,
- have read and understood the chapter on safety and the cautionary notes in these operating instructions and confirmed this by signing,
- are regularly vetted to ensure safe working.

1.4 Duty of trainees

Prior to commencing work, all persons assigned to working on FluidLab® PA closed-loop have a duty to:

- observe the basic regulations regarding operational safety and the prevention of accidents,
- read the chapter on safety and the cautionary notes in these operating instructions and to confirm that they have understood these by signing.

1.5 Risks involved in dealing with FluidLab® PA closed- loop

The Fluid Lab® PA closed-loop software is designed according to state of the art technology and in compliance with recognised safety regulations. However when using the system there is nevertheless a risk of physical or fatal injury to the user or third parties or of damage being caused to the machinery or other material assets.

Fluid Lab® PA closed-loop is to be used only:

- for its intended purpose and
- in an absolutely safe conditions.



Faults impairing safety must be rectified immediately!

1.6 Warranty and liability

In principle all of our „Terms and Conditions of Sale“ apply. These are available to the operating authority upon conclusion of the contract at the latest. Warranty and liability claims for persons or material damage are excluded if these can be traced back to one or several of the following causes

- Use of the machine not in accordance with its intended purpose
- Incorrect assembly, commissioning, operation and maintenance of the machine

- Operation of the machine using faulty safety equipment or incorrectly fitted or non operational safety or protective devices
- Non observance of notes in the operating instructions regarding transport, storage, assembly, commissioning, operation, maintenance and setting up of the machine
- Unlawful constructional modifications on the machine
- Inadequate monitoring of machine components subject to wear
- Incorrectly carried out repairs
- Catastrophes as a result of foreign objects and acts of force major.

Festo Didactic herewith rules out any liability for damage or injury to trainees, the training company and /or other third parties which may occur during the use / operation of the system other than purely in a training situation, unless such damage has been caused intentionally or due to gross negligence by Festo Didactic.

1.7

Use for intended purpose

This system has been developed and produced exclusively for vocational and further training in the field of automation and communication. The training authority and / or the instructors is / are to ensure that trainees observe the safety precautions described in the manual provided.

The use of the system for its intended purpose also includes:

- following all advice in the operating instructions and
- carrying out inspection and maintenance work.

2 Installation

Note The installation routine described applies to the FluidLab® PA closed-loop. FluidLab® PA closed-loop is delivered on CD.

2.1 Design FluidLab® PA closed-loop uses following basic components:

- FluidLab® PA closed-loop program files und LabVIEW® Runtime environment (Version 2013) (files from NI)
- EasyPortUSB driver (files from Festo Didactic)

2.2 FluidLab® PA closed-loop program files Table of the sub-folders created on your local system after the installation process has been finished successfully:

| Folder name | Description |
|-------------|--|
| AddFiles | Folder for additional components like icons, internet links, etc. |
| Settings | Folder where pre-settings are stored in. |
| German | Files for the German version of FluidLab® PA closed-loop |
| English | Files for the English language version of FluidLab® PA closed-loop. |
| Spanish | Files for the Spanish language version of FluidLab® PA closed-loop |
| French | Files for the French language version of FluidLab® PA closed-loop. |
| Swedish | Files for the Swedish language version of FluidLab® PA closed-loop. |
| Chinese | Files for the Chinese language version of FluidLab® PA closed-loop. |
| Portuguese | Files for the Portuguese language version of FluidLab® PA closed-loop. |

2.3 EasyPort USB driver The EcOCX driver is needed for communication between FluidLab® PA closed-loop software and EasyPort USB via USB cable.


2.4 LabVIEW® runtime engine Because FluidLab® PA closed-loop is developed with LabVIEW® of National Instruments® the software uses a runtime environment to be executed on your system.

2.5 Requirements for usage **System requirements:**

- PC with Windows XP/7/8
- Pentium III or equivalent
- 2 GB RAM
- 300 MB free hard disk space
- USB 2.0 oder serial interface
- graphics resolution 1280 x 1024 Pixel
- CD-ROM drive

Hardware:

The software FluidLab-PA® closed-loop is used in connection with the EasyPortUSB and the MPS-PA Compact Workstation, EduKit PA Basic+Advanced or any other equivalent station.



Hardware connections Compact Workstation – EasyPort USB

- | | |
|---|---------------------------------------|
| 1 | EasyPort USB |
| 2 | I/O terminal Syslink |
| 3 | SysLink cable |
| 4 | Analog terminal |
| 5 | Analogue cable, 15-PIN, parallel |
| 6 | Power supply 24 V DC, 4,5 A |
| 7 | Labor cable with Safty plug(red/blue) |
| 8 | USB Cable oder PC data cable RS 232 |

Cable connections

1. Connect the EasyPort USB after installation of the USB driver to the USB port of your computer.
2. Switch on the power supply to the EasyPort USB after establishing all electrical connections between Easyport and station.

2.6 Starting installation




It is advisable to exit all other programmes before you start installing FluidLab® PA closed-loop.

Insert the installation CD into the CD drive. An installation routine should start automatically and assists you throughout the installation process.

If the installation routine does not start automatically, open Windows Explorer and click the icon of the CD drive into which the CD has been inserted. Then click the “Start.exe” file.

2.7 Selecting the set-up language

Two different languages can be selected for the installation website including German and English. The language selection takes place in the Internet Explorer window.




Select language

2.8

The installation website shows the programmes for installation:

Welcome window

- EasyPort Software V2.3.1
- FluidLab-PA closed-loop V4.0
- FluidLab-PA MPS PA V3.1



Welcome window

By pressing the respective Button “Install” you get automatically into the installation routine.

Through the future steps leads an installation wizard.

2.9

Uninstall the FluidLab® PA closed-loop



FluidLab® PA closed-loop software can be automatically removed from your PC.


Click

“Uninstall FluidLab® PA closed-loop” in the start menu folder.

Please note that only FluidLab® PA closed-loop files are removed during the uninstall process, not files from other manufacturers.

3 Design and function

After the software is launched either by double clicking the icon on the desktop or clicking the shortcut in the start menu folder or double clicking the executable in the Windows Explorer the following window will appear.



FluidLab® PA closed-loop icon for Compact Workstation/EduKit PA

3.1 Programm administration

Since Windows 7 the programm administration of FluidLab®-PA closed-loop is located in „my documents“ of the logged in user.

Upon first activation of FluidLab®-PA closed-loop a new folder „FluidLab_closed_loop_Data_V4“ is generated in „my documents“. That folder includes all language files, setting files and the licence file.

Storage location:

...\Users\<Benutzername>\Documents\FluidLab_closed_loop_Data_V4

If this folder is deleted all made settings of the user can be reseted.

Administration


Administration for trainers/lecturers can be done by „left maus click“ with the function „run as administrator“. Therefore all settings (e.g. saved „default.txt“), language selection and menu inputs are saved to the Windows main program folder.

These modification are then available for every new user – as well after deleting the folder „FluidLab_closed_loop_Data_V4“ in „my documents“. Deliberate and und unconscious changes can be also simply reversed by deletion.

3.2

Main menu


FluidLab®-PA closed-loop starts with the main menu. From there it is possible to access to all functions.



| Number | Function |
|--------|---|
| 1 | Open the “Measuring and Control” window (not available in simulation mode) |
| 2 | Open the “Characteristics” window (not available in simulation mode) |
| 3 | Open the “Closed loop – 2 point” window |
| 4 | Open the “Closed loop - continuous” window |
| 5 | Initializing the EasyPort interface |
| 6 | “Open” button for loading existing FluidLab® PA closed-loop setup files. |
| 7 | “Save” button to create a new setup file or overwrite an existing one. |
| 8 | Show information |
| 9 | Language selection |
| 10 | Open the “Setup” window for setting up the FluidLab® PA closed-loop software. |
| 11 | Initialise communication to EasyPort |
| 12 | Version of FluidLab® PA |
| 13 | Display connected Easyport |
| 14 | License name |

3.3 Licence input

If the user is running the software for the first time, the licence has to be inserted. If running demo mode or at false input of the licence the input fields are visible. Enter licence “Name” and “Code” and confirm with “ok”. If the software is activated “run as administrator” the software can be licenced for all users (siehe 3.1).




License input

See backside of the Fluidlab PA closed-loop CD cover for license information.

3.4 Information

Click the “Information” button in the main window. A window appears containing various information such as copyrights and system requirements.




Information window

3.5

Setup

Click at the setup button in the start up window.
The following window will appear.




Setup window

Select from 3 different tank geometries. Click upon the tank and select the model.



Tank settings

For each selected tank geometry there are input fields available after activating the check-box “Tank-Parameter. Tank-Parameters consists of the declaration of the areas, heights and corresponding voltage measure values.




Tank-Parameter – Example for 10L Tank, rectangular

Notice

This software in combination with the EasyPort DA is only for measuring voltage signals from 0 to 10VDC.


Check all functions of each binary sensor and actuator.



Digital inputs/outputs in the setup window for Port1 and Port2

Note

It is recommended to check functions of analog sensors and actuators with the software before running any other experiment to ensure that all hardware connections have been established successfully.




Analog outputs in the setup window

Note

It is possible to swap the outputs channel 0 and 1 at the “Proportional valve”. The PCS Compact Workstation (until to 2005) has the pump assigned to output channel 1 (A_OUT1)!

Design and function

The analog signal of the sensor, normally 0...10V, has to be converted into its physical value.



Analog input channel 0

| Component | Description |
|---------------------|---|
| Channels | Analog input channels 0...3 |
| Volts | Input voltage of EasyPort |
| Factor | Factor for multiplying the input voltage Standard value: 1 |
| Offset | Zero offset factor Standard value: 0 |
| Filter | For damping the input signal with gliding average, 0...90 measure cycles Standard value: 0 |
| physical value | Indication of physical value |
| Einheitenfeld | Input field for physical unit |
| Max. physical value | Input field for maximum shown physical value for full scale |

This conversion of the scaling is based upon a straight line equation:

$$y = a \cdot x + b$$

Where:


a = factor;

b = Offset;

x = measure value and

y = physical value

Graph of straight line equation



Example:

A flow sensor with a measure transmitter reads out a voltage signal within a range of 0 to 10 V for a measuring range of 0.3 to 7.5 litres per minute.

In this case, factor “a” for a full scale value of 7.5 l/min calculates as follow:

$$a = \frac{y - b}{x} = \frac{7.5 - 0.3}{10} = 0.72$$

The offset is found by shifting of the line’s initial point to the origin at $y_0 = 0,3$ and $x_0 = 0$:

$$b = y_0 - a \cdot x_0 = 0.3 - 0.72 \cdot 0 = \underline{\underline{0.3}}$$

Example for factor:

Sensor: 0...200 bar

Signal: 0...10V

so the factor has to be = 20

Example for offset:

Sensor: 0...100 bar

Signal: 0...10V, for measurement 5 bar should be = 0V.

55 bar should be 5 Volt

so the offset has to be = -5

Eventually the factor has to be adjusted, too.

Design and function

Simulation

Check the box “Simulation” for operating the software without hardware station and Easyport.

At the startup of Fluid Lab® PA closed-loop always the file “default.txt” in the sub folder “Settings” is loaded. If you want to have the simulation mode selected every time you start Fluid Lab® PA closed-loop you should save the simulation settings in this file. Alternatively you have to load your preferred configuration every time you start Fluid Lab® PA closed-loop.

Inverting control ratio

It is possible to change the direction of the control ratio for 2-point and continuous controllers.

| Inverting control ratio | Description |
|-------------------------|--|
| 0 | Positive control ratio $y = 0 \dots 100\%$ (0...1), if $e > 0$ |
| 1 | Negative control ratio $y = 100 \dots 0\%$ (1...0), if $e < 0$ |

Y-offset for final control element

For continuous controller the final control element (pump or proportional valve) can be set to an offset value of the controller output.

3.6 Changing texts

FluidLab® PA closed-loop is designed with multi language support. The displayed window and popup texts are available in following languages:


- German
- English
- French
- Spanish
- Swedish
- Chinese
- Portugese
- ... other languages available upon request

3.6.1 Window texts

The window texts in FluidLab® PA closed-loop can be changed. Use an editor like Microsoft® Editor.

The relevant files are located in subdirectories of the FluidLab® PA closed-loop user folder and differ by their suffix (file name extension):

- German language text ...\\German\\Regeln.GER
- English language text ...\\English\\Regeln.ENG
- French language text ...\\French\\Regeln.FRA
- Spanish language text ...\\Spanish\\Regeln.SPA
- Swedish language text ...\\Swedish\\Regeln.SWE
- Chinese language text ...\\Chinese\\Regeln.CHN
- Portugese language text ...\\Portugese\\Regeln.POR
- ...



Microsoft® Editor for editing window texts

Layout of the text file

Every line starts with a number and a following colon. Behind the colon the caption text begins.

It is recommended not to change this layout. Only edit the text behind the colon!

Note

It is recommended to choose short texts for the window texts.

3.6.2 Pop up's


FluidLab® PA closed-loop provides a “Pop up” function, which helps you to orientate with every single component on the window.

If you move the mouse over a component and leave it there for just a split second a text will come up to show you information about the component.

The pop up's are collected in a text file which can be opened with Microsoft® Editor for example.

The relevant files are located in subdirectories of the FluidLab® PA closed-loop directory and differ by virtue of their suffix (file name extension):

- German pop up texts ...\\German\\popup.GER
- English pop up texts ...\\English\\popup.ENG
- French pop up texts ...\\French\\popup.FRA
- Spanish pop up texts ...\\Spanish\\popup.SPA
- Swedish pop up texts ...\\Swedish\\popup.SWE
- Chinese pop up texts ...\\Chinese\\popup.CHN
- Portugese Pop up texts ...\\Portuguese\\popup.POR
- ...



```

01bu:End
02 :Initialise
03 :ON/OFF
04 :Clear diagram
05 :Additional information
06 :Configure measure time
07 :Accept measure time
08 :Configure physical diagram scale (left)
09E0:In 0 sensor B102 flow rate - digital impulses
10E1:In 1 float switch S111 - overflow safety lower tank
11E2:In 2 float switch S112 - threshold upper tank
12E3:In 3 capacitive sensor B113 - min. limit lower tank
13E4:In 4 capacitive sensor B114 - max. limit lower tank
14E5:In 5 feedback S115 - 2way ball-valve V102 closed
15E6:In 6 feedback S116 - 2way ball-valve V102 opened
16E7:In 7 not used
17A0:Out 0 2way ball-valve V102 - OPEN
18A1:Out 1 heating unit E104 ON
19A2:Out 2 switch over relay K1 - manipulation of pump binary(0)/analog(1)
20A3:Out 3 pump P101 motor M1 binary ON
21A4:Out 4 relay K106 - activate proportional valve V106
22A5:Out 5 not used
23A6:Out 6 not used
24A7:Out 7 not used
25 :Manipulated output #(0..10V)
26 :setting of physical value
27 :Select manipulated output Y 0=prop.valve 1=pump
28 :Start measuring
29 :Switch manipulated value ON/OFF
30 :Manipulated output #manual or controller operation
31 :Print screen shot
32 :save screen as JPEG
    
```

Microsoft® Editor for editing the pop up texts

Layout of the text file

Every line starts with a number and a following colon. Behind the colon the pop up text begins. It is recommended not to change this layout. Only edit the text behind the colon!

To edit the text for the proportional valve for example (see picture below) edit line “21A4” in the text file.



Pop up for the proportional valve

Note


Please note that the length of the text must not exceed about 54 signs. If the text is longer it will be cut off. Multiline popups can be created with a spacer “#”.

All text files are prepared for the use of FluidLab® PA closed-loop with the MPS-PA Compact –Workstation or EduKit-PA Advanced.

3.7

Graph adjustment

The colors, line styles, line width etc. of the single graphs in the diagram can be modified. To do this, position the mouse cursor on the displayed line and press the left mouse button. A submenu for setting will be opened.




Graph adjustment

3.8 Measuring and Control

The Measuring and Control window is to analyze your actual system and to control every single element of it.

The “Measuring and Control” –function can be selected at the main window.



Measuring and Control window

Note

This function is only available when used in combination with an EasyPort. In the simulation mode this function is disabled.

Table of available functions to measure and control window

| Number | Function |
|--------|--|
| 1 | Switch on diagram zoom |
| 2 | Switch off diagram zoom |
| 3 | Select zoom zone |
| 4 | Switch courser to basic form |
| 5 | Select signals and colour of the curves |
| 6 | Select cycle time (min. 40ms or higher) |
| 7 | Digital input and outputs |
| 8 | Pull-down menu fort he manipulated value, can be switched ON/OFF by the button "control value ON/OFF" |
| 9 | Analogue outputs 0 ... 10V |
| 10 | Start/Stop reading of the values |
| 11 | control value ON/OFF |
| 12 | Cursor analysis fort he recorded curves |
| 13 | Reset cursor to the left upper corner of the graph |
| 14 | Print window (screenshot) Save window (screenshot) as JPG Save values to ASCII file |
| 15 | Auto scaling ON/OFF - input field for measure periode for recorder mode - switch over button for Auto Scaling or Recorder mode |
| 16 | Start postion of curser |

3.8.1 Example of how to measure a system response

This example describes how to measure a system response of the flow rate system for working with Compact-Workstation.

The window is layouted to be able to work in the easiest way possible. Just start at the top of the tool bar at the right side of the window and move down step by step. After completion do your measurement and solve the exercise.


1. Choose the analog input channel to display at the graph. (To work with the flow rate sensor choose channel 1)
2. Presetting: Click the “delete”-button to delete an old measurement. It is recommended to do this step before every new measurement exercise.
3. Choose the digital outputs.
Flow rate system: Ensure output bit 2 is disabled (digital control of the pump)
4. Set manipulated value to „DOUT3 pump“
5. Press the “start”-button to start the measurement. After that it will change to a “stop”-button with which you will have to stop the measurement again before proceeding.
6. Stellgröße ein- und ausschalten um ein Signal auf die Pumpe zu geben.
7. Use the “Cursor analysis” for analyzing the system response.
8. Documentation: Save the window as a picture (JPG-file) on your system or print it to a connected printer.

3.9

Characteristics

Characteristic curves can be measured in this menu.

- flow rate of the pump for the voltage 0 ... 10V and 10V ... 0V
- pressure rate of the pump for the voltage 0 ... 10V and 10V ... 0V
- coherence between flow rate and pressure for a specific voltage




Window Characteristics

Table of available functions in characteristic window

| Number | Function |
|--------|--|
| 1 | Curve |
| 2 | Clear diagram or open a bmp file |
| 3 | Selection of recording characteristic curve –experiment: 1. flow rate of the pump for the voltage 0 ... 10V and 10V ... 0V 2. pressure rate of the pump for the voltage 0 ... 10V and 10V ... 0V 3. coherence between flow rate and pressure for a specific voltage |
| 4 | Digital and Analogs inputs |
| 5 | Digital outputs |
| 6 | Select analogue output |
| 7 | Setting of the experiment time [s] for experiment 1. or 2. |
| 8 | Indication of the voltage curve for experiment 1. or 2., input slider for experiment 3. |
| 9 | Start/Stop experiment |
| 10 | Cursor analysis |
| 11 | Print window (screenshot) Save window (screenshot) as JPG Save values to ASCII file |

3.10 Closed loop – 2 point

With the “Closed loop – 2 point”-function you are able to realize a closed loop 2- point control for example for the level system.



Closed loop – 2 point control window in simulation mode

Procedure using Simulation


- Select control system (3)
- diagram and settings are set automatically
- Set controller's parameters (6)
 - Set point (7) and switching difference (8).
- For simulation additionally: select simulation switch ON(3)
- Start the closed loop control with the “Start”-button(10).
- Stop the closed loop control with the “Stop”-button(10)
- Documentation(13)

Table of available functions in closed loop 2 point control window

| Nummer | Funktion |
|--------|--|
| 1 | Curve |
| 2 | Clear diagram and model or open a bmp file |
| 3 | Select control system |
| 4 | Switch ON/OFF simulation window (only accessible if using Simulation mode) |
| 5 | Digital inputs |
| 6 | Select manipulated output |
| 7 | Setting set point value SP |
| 8 | Setting of switching distance |
| 9 | Simulation window of the system |
| 10 | Start/Stop experiment |
| 11 | Print window (screenshot) Save window (screenshot) as JPG Save values to ASCII file |
| 12 | Auto scaling ON/OFF - input field for measure periode for recorder mode - switch over button for Auto Scaling or Recorder mode |

3.11 Continuous loop control

With the “Closed loop – continuous”-function you are able to realize a continuous closed loop control for example the pressure system.



Window of closed loop control (continuous) of the level system in simulation mode

Procedure using Simulation

- Select control system (3)
- For simulation additionally: select switch ON (4)
- Choose the controller you prefer and set its parameters (10).
- Start the closed loop control with the “Start”-button (12).
 - Watch and work with the closed loop control.
- Stop the closed loop control with the “Stop”-button (12)
- Documentation (13)

Table of available functions in closed loop control window

| Number | Function |
|--------|--|
| 1 | Curve |
| 2 | Clear diagram or open a bmp file |
| 3 | Select Closed-Loop |
| 4 | Switch ON/OFF simulation window (only accessible if using Simulation mode) |
| 5 | Settings for process value will be automatically selected |
| 6 | Setting setpoint |
| 7 | Select manipulated output |
| 8 | Setting set point value SP |
| 9 | Simulation window of the system (only accessible if using Simulation mode) |
| 10 | Setting of controller type and parameters P P-controller, adjustable proportional gain Kp I I-controller, adjustable integral time TI PI[math] PI-controller, mathematical controller in parallel structur adjustable proportional gain Kp und integral time TI PI PI-controller, technical controller in series structur, DIN EN 60027-6 adjustable proportional gain Kp and reset time Ti PD PD-controller, technical controller, series structur, DIN EN 60027-6 adjustable proportional gain Kp, derivative time Td and control ouput y0 at working point if e=0 PID PID-controller, technical controller, series structur, DIN EN 60027-6 adjustable proportional gain Kp, reset time Ti and derivative time Td |
| 11 | Open controller block function diagram |
| 12 | Start/Stopp experiment |
| 13 | Documentation (only when execution stopped): - cursor analysis - Print window (screenshot) - Save window (screenshot) as JPG - Save values to ASCII file |
| 14 | Auto scaling ON/OFF - input field for measure periode for recorder mode - switch over button for Auto Scaling or Recorder mode |


3.12

Saving results as ASCII files

In all 4 menus the measured values of the data logging can be save into an ASCII file. This file can be imported in Microsoft® Excel e.g. for further documentation or calculations.

Example how to import the data file into Microsoft® Excel:

1. Record the measuring
2. Click the button „ASCII“(13) to save the values to a file
3. Open Mircrosoft® Excel
4. Open the saved file
Menu “File” → Open - change the file filter to “all files (*.*)
5. Follow the convert assistant as shown below




Microsoft® Excel convert-assistant, Step 1 of 3

Options to choose at Step 1 of 3:

Original file type: separated

Click on „Next >“



Microsoft® Excel convert-assistant, Step 2 of 3


Options to choose at Step 2 of 3:

Use successive separators as one sign

Separator: tabulator
 blank

Sign to identify text: “

Click on „Next >“



Microsoft® Excel convert-assistent, Step 3 of 3

Options to choose at Step 3 of 3:

Data format of columns: Standard

Click on „finish“

The data will now be imported into Excel.

4 Trouble shooting

4.1

Easyport

Questions: No measured values appear?

- Check whether voltage is applied to the system
- Check whether all cables are properly connected.
- Check the connection status. The green status LED indicates two states:
 - Flashing at a frequency of 1 Hz: Status immediately after start-up, the EasyPort USB module has not yet started communicating.
 - Pulsating flashing: The EasyPort USB module has been addressed. The address is indicated every 2 seconds by a series of briefly flashing light signals.
- Terminate software which could also be connected to the Easyport.
- Check the address of the Easyport and in the settings of the software setup.

4.2

User interface

Questions: My measured values are wrong?

If the values do not correspond with the physical quantities, then factor and offset must be set in the setup window (spanner icon).

Questions: FluidLab® PA closed-loop does not start?

LabVIEW Runtime environment is not installed, please install.

Questions: My window resolution seems too small?

The software is set to 1042 x 7680 pixels or higher. Please set your window to this resolution in Windows®.

Questions: My measured values appear, but there are no lines in the diagram?

Check the minimum and maximum scale values. You may have to set them to the momentary measured values.

Check the colors of the characteristic curves (white on white?)

Questions: My measured values exhibit extreme oscillation?

Change the default for damping of the signals in the setup window.

For online support please contact our Competence Center for Process Automation:
info@adiro.com


More FAQ are available at:

http://www.adiro.com/en/didactic/faq/faq_fluidLab-PA.php


5 Appendix

5.1 Examples for system responses


See screen shots below for detailed information of how to measure system responses with FluidLab PA closed-loop. All results shown refer to the work with PCS Compact-Workstation.




System response flow rate system




System response level system without compensation



System response of level system with compensation




System response pressure system




System response of temperature system

5.2 Examples for closed loop controls


See screen shots below for detailed information of how to run closed loop controls with FluidLab® PA closed-loop. All results shown refer to the work with PCS Compact-Workstation.




Closed loop control of level system



Closed loop control of flow rate system with disturbances



Closed loop control of pressure system via pump



Closed loop control of pressure system via proportional valve

5.3 Controller parameters

The following table shows examples for controller parameters for the work with MPS-PA Compact-Workstation.

| Controller | Level | Flow rate pump | Flow rate prop. valve | Pressure pump | Pressure prop. valve | Temperature |
|------------|---|--|--|--|---|-------------|
| switching | | | | | | |
| 2-point | X | - | - | - | - | X |
| continuous | | | | | | |
| P | w = 0,3 K _p = 5,0 w _{max} = 0,6 | w = 0,3 K _p = 5,0 w _{max} = 0,55 | - | w = 0,5 K _p = 1,5 w _{max} = 1,0 | - | - |
| I | w = 0,3 T _i = 2,0s w _{max} = 0,6 | w = 0,3 T _i = 2,0s w _{max} = 0,6 | | | | - |
| PI[math] | w = 0,3 K _p = 5,0 T _i = 5,0s w _{max} = 0,6 | | | | | - |
| PI | w = 0,3 K _p = 5,0 T _i = 25,0s w _{max} = 0,6 | w = 0,3 K _p = 1,0 T _i = 2,0s w _{max} = 0,6 | w = 0,15 K _p = 1,0 T _i = 1,0 w _{max} = 0,3 | w = 0,5 K _p = 1,0 T _i = 1,0s w _{max} = 1,0 | w = 0,5 K _p = 1,0 T _i = 1,0s w _{max} = 1,0 | - |
| PID | | | | w = 0,5 K _p = 1,0 T _i = 1,0s T _d = 0,1s w _{max} = 1,0 better K _p = 0,6 - no oscillation | w = 0,5 K _p = 0,4 T _i = 3,0s T _d = 1,0s w _{max} = 1,0 | - |

5.4 I/O assignment list Worksheet

| Symbol | PIN assignment | EasyPort/Simbox address | PLC address | Description |
|--|----------------|-------------------------|-------------|-------------|
| Binary inputs (XMA1) | | | | |
| | I 0 | I 0 | %I0.0 | |
| | I 1 | I 1 | %I0.1 | |
| | I 2 | I 2 | %I0.2 | |
| | I 3 | I 3 | %I0.3 | |
| | I 4 | I 4 | %I0.4 | |
| | I 5 | I 5 | %I0.5 | |
| | I 6 | I 6 | %I0.6 | |
| | I 7 | I 7 | %I0.7 | |
| Binary outputs (XMA1) | | | | |
| | Q 0 | Q 0 | %Q0.0 | |
| | Q 1 | Q 1 | %Q0.1 | |
| | Q 2 | Q 2 | %Q0.2 | |
| | Q 3 | Q 3 | %Q0.3 | |
| | Q 4 | Q 4 | %Q0.4 | |
| | Q 5 | Q 5 | %Q0.5 | |
| | Q 6 | Q 6 | %Q0.6 | |
| | Q 7 | Q 7 | %Q0.7 | |
| Analogue inputs (X2) – AI = analog input channel | | | | |
| | UE1 | AI 0 | (P)IW256 | |
| | UE2 | AI 1 | (P)IW258 | |
| | UE3 | AI 2 | (P)IW260 | |
| | UE4 | AI 3 | (P)IW262 | |
| Analogue outputs (X2) – AO = analog output channel | | | | |
| | UA1 | AQ 0 | (P)QW256 | |
| | UA2 | AQ 1 | (P)QW258 | |